

# AN13223

## PN7160 dynamic load modulation amplitude guide

Rev. 1.1 — 13 September 2021

Application note  
COMPANY PUBLIC

### Document information

Information	Content
Keywords	NFCC, NFC, DLMA, PN7160
Abstract	This document provides information about PN7160 dynamic load modulation amplitude (LMA) feature.



## Revision history

Rev	Date	Description
1.1	20210913	Security status changed into "Company public", no content change
1.0	20210825	Initial version

## 1 Introduction

---

The PN7160 includes a specific feature called “dynamic LMA control” which makes it possible to adapt the load modulation amplitude to the received field strength.

With this capability, the device can generate an optimized signal in card mode and provide better performances by improving:

- communication distances
- interoperability with readers


This document is about to explain the PN7160 DLMA principle and the methodology to configure it.

## 2 PN7160 DLMA principle


### 2.1 TX settings lookup table

This methodology is based on a 40 entries TX settings lookup table. This table is called “universal table” and is fixed by PN7160 FW. Each entry (sequence) refers to a unique combination of TX setting (TXLDO output voltage, TX drop, number of drivers, BPSK available) which generates an estimated TX output voltage.

Ratio between two consecutive TX values is equal to 1/1.1. This shape corresponds to an ISO passive card answer. Some TX setting sequences are duplicated to consider TXLDO maximum voltage availability. The figure below illustrates calculated TX output voltages versus lookup table entries:



Pay attention that TX output voltage does not mean antenna voltage. Matching network and antenna will apply a gain to the TX output to create the measured LMA, this gain is by default unknown by FW.



Antenna gain should be set using the parameter **DLMA\_LMA\_TX\_SHIFT\_AB(F)**. This parameter is calculated using the ratio between the target LMA @ 0A/m and the measured LMA @ 1.5A/m. Complete formula is available below:

$$\begin{aligned}
 \text{LMA/TX (target (@0A/m))} &= \frac{\text{LMA target (mVpp)}}{\text{Equiv TX Voltage (Vpp)}} \\
 \text{LMA/TX(measured (@1.5A/m))} &= \frac{\text{LMA measured (mVpp)}}{\text{Equiv TX Voltage (Vpp)}} \\
 \text{DLMA\_LMA\_TX\_SHIFT\_AB(F)} &= \frac{\log\left(\frac{\text{LMA/TX measured (@1.5A/m)}}{\text{LMA/TX target (@0A/m)}}\right)}{\log(1.1)}
 \end{aligned}$$

Figure 3. Antenna and matching network gain calculation

### 2.2 RSSI scaling


External field strength measurement is done using interpolated RSSI which is a combination of AGC and ADC measurements. Even if RSSI coefficients are trimmed during PN7160 IC production, RSSI global function spreads. Production equipment limits (±12%), and antenna matching networks external components (±10%) are the main reason of this discrepancy. RSSI expected slope is 75/(A/m). If the measured RSSI slope differs, a correction parameter is available: **DLMA\_RSSI\_H\_SCALE\_AB(F)**.

This parameter is calculated using a ratio between reference and measured RSSI at H=1A/m. As RSSI function is more linear at high field strength than at low field strength, a measurement is done at H=5A/m and result is divided by 5:

$$\text{DLMA\_RSSI\_H\_SCALE\_AB(F)} = \text{round}\left(\frac{\text{RSSI reference (@1A/m)}}{\text{RSSI measured (@5A/m)/5}} \times 128\right)$$

Figure 4. RSSI scaling factor calculation

Figure below illustrates RSSI correction:



### 2.3 DLMA options

To create a correspondence between internal measure of field strength (RSSI) and TX lookup table, an internal algorithm is used by FW. TX choice in the lookup table depends on:

- Interpolated RSSI value
- **DLMA\_LIMIT\_TXLDO\_AB(F)** TXLDO maximum available output voltage (from 3 V to 5.25 V). This parameter is set by register. Rmk: TX output voltage is directly proportional to TXLDO output voltage. Then high LMA are not achievable with low TXLDO output voltage.
- **DLMA\_ENA\_SINGLE\_TX\_AB(F)** number of TX drivers (mode 1&2) is set by register. It allows usage of one or two TX drivers when enable and forbid single driver when disable. Rmk: this option is suitable to achieve low LMA.
- **DLMA\_ENA\_BPSK\_AB(F)** BPSK modulation (mode 3) set by register gives the possibility to enable or disable BPSK modulation (roughly multiply by a factor of two TX output voltage). Rmk: this option is suitable to achieve high LMA.

Below the relation between RSSI and TX output voltage with previous options enabled/disabled:




Figure 6. PN7160 DLMA options

## 2.4 DLMA parameters

PN7160 DLMA is configured via 3 parameters (see [\[1\]](#) for more details):

- **DLMA\_CTRL**: enable/disable DLMA and options definition
- **DLMA\_RSSI**: define RSSI threshold values
- **DLMA\_TX**: to define TX settings lookup table

### 3 PN7160 DLMA configuration table

An EXCEL file, delivered as part of the PN7160 DLMA configuration package (see [3]), is offered to help setting DLMA configuration.

#### 3.1 DLMA\_CTRL parameter

'DLMA\_CTRL Settings' sheet is used to define configuration options (single/dual driver, BPSK, TXLDO max output). It is also the place where measurements of RSSI @ 5A/m, LMA and internal index @ 1.5A/m are reported. These measurements are used to calculate TX shifting and RSSI scaling factors for type A&B and F.




Figure 7. 'DLMA\_CTRL Settings' sheet – part 1

A second part of the sheet is dedicated to phase compensation mechanisms. Phase compensation (AGC, TX, ATE) controls for type F, type A&B are included in DLMA\_CTRL register:





Figure 8. 'DLMA\_CTRL Settings' sheet – part 2

Remark: Only highlighted cells can be modified.



3.2 DLMA\_RSSI parameter

'DLMA RSSI Settings' sheet is used to define target LMA @ 0A/m and to define the field strength thresholds. Type A&B and Type F definitions are independent. Another column is dedicated to arbitrary phase definition. This phase offset is included in a range of -127° to +127°.



### 3.3 DLMA\_TX parameter

This sheet is more informative one, as the TX lookup table is fixed and cannot be modified.




Figure 11. 'DLMA TX Settings' sheet

## 4 DLMA configuration procedure

Before starting any measurement/configuration please be sure that PN7160 setup is functional, that matching is done (see [2]) and sanity check have been done.

The DLMA configuration procedure requires then dedicated FW version been loaded into PN7160. This specific FW, as part of the PN7160 DLMA configuration package (see [3]), is indeed implementing customized notification required for the DLMA calibration Section 4.5.

The FW update procedure is further detailed in dedicated PN7160 documentation according to the target environment (Android, Linux or RTOS/NullOS).

Pay attention that this specific FW version MUST only be used for the DLMA configuration purpose since it does not include full PN7160 features validated.

### 4.1 Step0: RSSI Rext setting

PN7160 DLMA is based on field strength internal measurement in other words on RSSI feature. This function is trimmed in production with polynomial combination of ADC and AGC value. Another parameter is the value of RX path resistor (Rext):




Figure 12. Rext resistor

Value of this external component is by definition unknown by NFCC system, so it must be set externally. This is done thanks to REXT\_RSSI\_CFG parameter split into 2 parts:

- Rext value referenced as wRextAGCCor (in Ohms)
- A coefficient used to compensate a bend in the transition from ADC region to AGC region referenced as wRextGainCor


See [1] for more details about REXT\_RSSI\_CFG parameter definition.

As guidance:

Table 1. REXT\_RSSI\_CFG parameter guidance

Rext	wRextGainCor		wRextAGCCor	
560Ω	1021	0x03FD	560	0x0230
1k0Ω	1027	0x0403	1000	0x03E8
1k3Ω	1050	0x041A	1300	0x0514
2k2Ω	1080	0x0438	2200	0x0898
3k3Ω	1090	0x0442	3300	0x0CE4
5k6Ω	1110	0x0456	5600	0x15E0


To verify if Rext register is correctly set, RSSI versus field strength must be measure and RSSI shape should be linear (no bend at ADC → AGC region) as presented below:



### 4.2 Step1: DLMA RSSI threshold settings

Customer needs to define independently Type A&B and Type F target LMA versus field strength shape. To proceed, user will use 'DLMA\_RSSI Settings' sheet. As a starting point two shapes are proposed. They can be adapted to user constraints.

To do this, customer needs to define independently Type A&B and Type F target LMA @ 0A/m and RSSI thresholds. As a reminder, only yellow highlighted cells can be changed.



LMA function is a decreasing function (no possibility to increase). Ratio between two consecutive steps is 1.1. If a bigger ratio is needed, a step could be left, as shown in above case (surrounded in green).

### 4.3 Step2: DLMA option settings

Customer must define independently Type A&B and Type F target LMA PN7160 DLMA options:

- Enabling/disabling DLMA
- Allowing use of single driver possibility (enable: dual and single driver | disable: only dual)
- Allowing use of BPSK
- Defining TXLDO maximum allowed voltage depending on DC-DC use or not and V<sub>up</sub> characteristics.

To proceed, user will use 'DLMA\_CTRL Settings' sheet.

### 4.4 Step3: DLMA default settings

Before performing DLMA calibration, default TX and RSSI DLMA\_CTRL register value should be applied (meaning **DLMA\_LMA\_TX\_SHIFT** = 0 and **DLMA\_RSSI\_H\_SCALE** = 128). To make it easier a function has been implemented in the PN7160 DLMA configuration table. Answer "Yes" to the question: "RSSI TX Default settings?". This will darken unnecessary cells and set default values, as presented below:





Figure 15. 'DLMA CTRL Settings' sheet – default settings mode

NCI command is then generated and must be applied to the PN7160 IC before starting calibration, please refer to 'DLMA NCI CMD' sheet:




### 4.5 Step4: DLMA calibration

This step consists in measuring PN7160 DLMA internal states and LMA for type A&B and type F when 1.5A/m and 5A/m field strength is applied. Following steps requires then an ISO bench to be performed. To measure calibration parameters, PN7160 DLMA "debug" mode need to be enabled. This "debug" mode, only available in PN7160 DLMA configuration-specific FW version, is controlled thanks to the following NCI commands:

```
// DLMA Debug mode enable: 20020601A01D028000
// DLMA Debug mode disable: 20020601A01D020000
// DLMA Debug read status: 20030301A01D
```

This option makes readable PN7160 internal states, meaning RSSI unscaled and index of the TX lookup table. To make customer measurement easier, a decoding function is available in the 'DLMA CTR Settings' sheet. Below is an example of adb log extract and decoding function:



To perform measurements, PN7160 must be set in card mode.

Referring to chapter [Section 2](#), the followings measurements are needed for type A&B and for type F:

- RSSI meas. @5 A/m
- LMA meas. @1.5 A/m
- ID meas. @1.5A/m

When it is done 'DLMA CTRL Settings' sheet entries should be filled. And most important thing is the answer to the question: "RSSI TX Default settings?" should be put back to "No":




Figure 18. 'DLMA CTRL Settings' sheet – calibration mode

Calibration is now done, new parameters **DLMA\_LMA\_TX\_SHIFT**, **DLMA\_RSSI\_H\_SCALE** must be applied to the PN7160 IC, please refer to 'DLMA NCI CMD' sheet:

```
DLMA_CTRL 20 02 10 01 A0 AF 0C 83 C0 7B A0 00 83 C0 80 A0 00 77 08
```

Figure 19. 'DLMA NCI CMD' sheet – calibrated command

#### 4.6 Step5: DLMA final measurement

LMA versus field strength is performed again and experimentation should fit customer requirements:




Figure 20. LMA and target versus field strength measurement for type A&B




Figure 21. LMA and target versus field strength measurement for type F

RSSI versus field strength measurement are also performed to verify that RSSI fit theoretical curve ( $75/A \cdot m^{-1}$ ):




Figure 22. RSSI versus field strength measurement



## 5 Abbreviations

Table 2.

Abbr.	Meaning
A/m	Ampere per meter (magnetic field strength measurement unit)
AGC	Automated Gain Control
AN	Application Note
DLMA	Dynamic Load Modulation Amplitude
FW	FirmWare
Hmin / Hmax	Minimal and Maximum magnetic field strength
H-field	Magnetic field
IC	Integrated Circuit
ISO/IEC	International Standard Organization / International Electrotechnical Community
mA	milli Ampere
NFC	Near Field Communication
NFCC	NFC Controller (i.e. PN7160)
PCD	Proximity Coupling Device (Contactless reader)
PICC	Proximity Integrated Circuit Card (Contactless card)
RF	Radiofrequency
RSSI	Received Signal Strength Indication
V	Voltage
Vpp	Peak to peak voltage

## 6 References

---

- [1] UM11495 - PN7160 user manual
- [2] AN13219 - PN7160 Antenna design and matching guide
- [3] SW6780 - PN7160 DLMA configuration package

## 7 Legal information

### 7.1 Definitions

**Draft** — A draft status on a document indicates that the content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included in a draft version of a document and shall have no liability for the consequences of use of such information.

### 7.2 Disclaimers

**Limited warranty and liability** — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

**Right to make changes** — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

**Suitability for use** — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

**Applications** — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

**Terms and conditions of commercial sale** — NXP Semiconductors products are sold subject to the general terms and conditions of commercial sale, as published at <http://www.nxp.com/profile/terms>, unless otherwise agreed in a valid written individual agreement. In case an individual agreement is concluded only the terms and conditions of the respective agreement shall apply. NXP Semiconductors hereby expressly objects to applying the customer's general terms and conditions with regard to the purchase of NXP Semiconductors products by customer.

**Export control** — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

**Evaluation products** — This product is provided on an "as is" and "with all faults" basis for evaluation purposes only. NXP Semiconductors, its affiliates and their suppliers expressly disclaim all warranties, whether express, implied or statutory, including but not limited to the implied warranties of non-infringement, merchantability and fitness for a particular purpose. The entire risk as to the quality, or arising out of the use or performance, of this product remains with customer.

In no event shall NXP Semiconductors, its affiliates or their suppliers be liable to customer for any special, indirect, consequential, punitive or incidental damages (including without limitation damages for loss of business, business interruption, loss of use, loss of data or information, and the like) arising out of the use of or inability to use the product, whether or not based on tort (including negligence), strict liability, breach of contract, breach of warranty or any other theory, even if advised of the possibility of such damages.

Notwithstanding any damages that customer might incur for any reason whatsoever (including without limitation, all damages referenced above and all direct or general damages), the entire liability of NXP Semiconductors, its affiliates and their suppliers and customer's exclusive remedy for all of the foregoing shall be limited to actual damages incurred by customer based on reasonable reliance up to the greater of the amount actually paid by customer for the product or five dollars (US\$5.00). The foregoing limitations, exclusions and disclaimers shall apply to the maximum extent permitted by applicable law, even if any remedy fails of its essential purpose.

**Translations** — A non-English (translated) version of a document, including the legal information in that document, is for reference only. The English version shall prevail in case of any discrepancy between the translated and English versions.

**Security** — Customer understands that all NXP products may be subject to unidentified vulnerabilities or may support established security standards or specifications with known limitations. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP.

NXP has a Product Security Incident Response Team (PSIRT) (reachable at [PSIRT@nxp.com](mailto:PSIRT@nxp.com)) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

### 7.3 Licenses

**Purchase of NXP ICs with NFC technology** — Purchase of an NXP Semiconductors IC that complies with one of the Near Field Communication (NFC) standards ISO/IEC 18092 and ISO/IEC 21481 does not convey an implied license under any patent right infringed by implementation of any of those standards. Purchase of NXP Semiconductors IC does not include a license to any NXP patent (or other IP right) covering combinations of those products with other products, whether hardware or software.

### 7.4 Trademarks

Notice: All referenced brands, product names, service names, and trademarks are the property of their respective owners.

**NXP** — wordmark and logo are trademarks of NXP B.V.

**Tables**

Tab. 1. REXT\_RSSI\_CFG parameter guidance ..... 11      Tab. 2. .... 17

## Figures

Fig. 1.	TX settings lookup table .....	4	Fig. 15.	'DLMA CTRL Settings' sheet – default settings mode .....	13
Fig. 2.	Matching network and antenna gain .....	4	Fig. 16.	'DLMA NCI CMD' sheet – default settings command .....	14
Fig. 3.	Antenna and matching network gain calculation .....	5	Fig. 17.	DLMA debug mode use .....	14
Fig. 4.	RSSI scaling factor calculation .....	5	Fig. 18.	'DLMA CTRL Settings' sheet – calibration mode .....	15
Fig. 5.	RSSI correction .....	5	Fig. 19.	'DLMA NCI CMD' sheet – calibrated command .....	15
Fig. 6.	PN7160 DLMA options .....	6	Fig. 20.	LMA and target versus field strength measurement for type A&B .....	15
Fig. 7.	'DLMA_CTRL Settings' sheet – part 1 .....	8	Fig. 21.	LMA and target versus field strength measurement for type F .....	16
Fig. 8.	'DLMA_CTRL Settings' sheet – part 2 .....	8	Fig. 22.	RSSI versus field strength measurement .....	16
Fig. 9.	'DLMA RSSI Settings' sheet - Type A&B .....	9			
Fig. 10.	'DLMA RSSI Settings' sheet - Type F .....	9			
Fig. 11.	'DLMA TX Setings' sheet .....	10			
Fig. 12.	Rext resistor .....	11			
Fig. 13.	RSSI shape .....	12			
Fig. 14.	'DLMA RSSI Settings' sheet .....	12			

---

## Contents

---

<b>1</b>	<b>Introduction</b> .....	<b>3</b>
<b>2</b>	<b>PN7160 DLMA principle</b> .....	<b>4</b>
2.1	TX settings lookup table .....	4
2.2	RSSI scaling .....	5
2.3	DLMA options .....	6
2.4	DLMA parameters .....	7
<b>3</b>	<b>PN7160 DLMA configuration table</b> .....	<b>8</b>
3.1	DLMA_CTRL parameter .....	8
3.2	DLMA_RSSI parameter .....	9
3.3	DLMA_TX parameter .....	10
<b>4</b>	<b>DLMA configuration procedure</b> .....	<b>11</b>
4.1	Step0: RSSI Rext setting .....	11
4.2	Step1: DLMA RSSI threshold settings .....	12
4.3	Step2: DLMA option settings .....	13
4.4	Step3: DLMA default settings .....	13
4.5	Step4: DLMA calibration .....	14
4.6	Step5: DLMA final measurement .....	15
<b>5</b>	<b>Abbreviations</b> .....	<b>17</b>
<b>6</b>	<b>References</b> .....	<b>18</b>
<b>7</b>	<b>Legal information</b> .....	<b>19</b>

---

Please be aware that important notices concerning this document and the product(s) described herein, have been included in section 'Legal information'.

---

© NXP B.V. 2022.

All rights reserved.

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: [salesaddresses@nxp.com](mailto:salesaddresses@nxp.com)

Date of release: 13 September 2021  
Document identifier: AN13223